

Installation Guide

Arcisan ceiling mounted Ø200mm showerhead - AR02120/AR02121

IMPORTANT INFORMATION

- Operating static pressure is 150—500kpa. If pressure exceeds this, then an approved pressure limiting valve must be fitted.
- Shower may not be suitable for use with gravity-fed, low and unequal pressure supply networks, instantaneous water heaters, tempering valves and thermostatic mixing valves.
- Where showers incorporate flow controllers, care shall be exercised during installation to ensure that the male connecting threads do not damage the flow controllers.
- To be installed in accordance with AS/NZS 3500.

- 1 - Apply thread seal to 1/2" male thread coming out of ceiling.
- 2 - Slide cover plate over end of ceiling arm.
- 3 - Screw the wall arm onto the male thread, ensuring a water tight seal.
- 4 - Screw showerhead onto end of wall arm.

Maintenance and Care

- Using a soft cloth with a mild detergent or soap is all that is required to clean surfaces.
- Do not use abrasive cream cleaners or citrus based cleaning products. These will damage the surface.

streamline

www.streamlineproducts.com.au | Ph: 1300 735 352

Dimensions are in millimeters and are subject to manufacturing variations. Streamline reserves the right to vary specifications at any time without notice. Information provided within this installation sheet is correct at the date of printing. Please confirm all particulars against your product prior to installation.

Version: 1.0 - July 2018

WaterMark
WM-022818
AS/NZS 3662
ARCISAN