


SAVOIR

ZSA671.CC

Exploded



ZAV000.9500C- (HANDLE)
REPLACE C- WITH THE TYPE OF FINISH:
CC = CHROME
CW = CHROME / WHITE LACQUERED
CN = CHROME / BLACK LACQUERED
CR = CHROME / RED LACQUERED
CL = CHROME / BLUE LACQUERED
CV = CHROME / GREEN LACQUERED