

Cleaning, Care and Maintenance Instructions for Arcisan Solid Surface Products

Thankyou for your purchase of a quality Arcisan product. Every Arcisan product is manufactured with the utmost care, to meet the highest Australian standards and using the care instructions below, we are sure it will serve you reliably for many years to come.

Daily maintenance: to clean your solid surface product, use soapy water or household detergents. Gel or abrasive detergents are recommended, taking care to thoroughly rinse the surface after. If using an abrasive Scotch-Brite pad the original opaque finish of the solid surface, will be maintained.

Avoid the use of aggressive chemical products such as acetone, trielin, strong acids. Some substances such as ink, make-up and dyes, as well as cigarettes may leave stains and marks on the surface.

Scratches, cigarettes burns and stubborn stains may be removed by using an abrasive Scotch-Brite pad and an household abrasive cleaner. If the defect is still visible, repeat repeat the treatment using a very fine sand paper (1200 grain).

Please leave the instructions with the owner.

ARCISAN